What you will need:

15mm spanner/wrench or 15mm pedal spanner/wrench



Step 1: Remove the left-side pedal:

Place the open end of the spanner/wrench onto the square, flat surface between the pedal and pedal arm (the crank). Turn in an counter-clockwise direction - reverse to pedalling direction, like as if you were applying the brakes. This direction applies to both pedals.



Step 2: Remove the right-side pedal:

Place the open end of the spanner/wrench between the pedal and crank arm. Turn in a clockwise direction.



Step 3: Installing Pedals:

- 1. Identify Left vs Right pedal. There is a "L" or "R" stamped into the metal part of the pedal near the threaded part that looks like a screw. Note: they are not the same!!
- 2. Install the left hand pedal first. You will have to screw it in COUNTER-CLOCKWISE because the threading is the reverse of a normal screw. DO NOT USE THE WRENCH until you are ready to tighten it for the final few turns. Tighten it down until you can't anymore.
- 3. Install the right hand pedal. This one threads in CLOCKWISE, like a normal screw. Follow the same principals as discussed in step 2 for the left pedal.

